





## INSTALLATION INSTRUCTIONS FOR THE MANUAL CALL POINT MODELS WCP6A-xC01....,WPC6B-xC01....,WCP6B-xC02....









## KAC INSTALLATION INSTRUCTIONS FOR THE MANUAL CALL POINT MODELS WCP6A-xC01....,WPC6B-xC01....,WCP6B-xC02....







The generic part codes detailed on this data sheet contain a number of 'X' digits to cater for product variation as follows:-

Digit 6 - Product Colour Digit 10 - Mounting (Surface or Flush) Digit 11 - Element (Glass or Reseattable)

See WCP label for details.

(including variations).

WCP products are supplied with flying leads to enable connection to 3rd party

PCB boards (supplied by

others).

